



INSTRUCTIONS FOR INSTALLING FIELD M + MG 2

CONTROLS WITHOUT COLLARS



CONTROL SIZE (A)	10	12	14	16	18	20	24	28	32
CORRECT COLLAR LENGTH (B)	4-3/8	5-3/4	7-1/8	8-3/8	8-1/4	9-5/8	12-3/8	13-1/8	15-3/4

BE SURE TO USE CORRECT COLLAR LENGTH. TOO SHORT OR TOO LONG MEANS A LESS EFFECTIVE CONTROL.