



**RESISTOR INSTALLATION
FOR ANY POWER STEALING TYPE
OF THERMOSTAT**



TYPICAL MODELS
HONEYWELL: T8400, T8000, T8700
CHRONOTHERM IV/ MODELS: T8500 & T8600
WHITE ROGERS: 1F90-371

CONNECT RESISTOR BETWEEN
T1/24VAC AND T2


**RESISTOR INSTALLATION
FOR ANY POWER STEALING TYPE
OF THERMOSTAT**



TYPICAL MODELS
HONEYWELL: T8400, T8000, T8700
CHRONOTHERM IV/ MODELS: T8500 & T8600
WHITE ROGERS: 1F90-371

CONNECT RESISTOR BETWEEN
T1/24VAC AND T2


**RESISTOR INSTALLATION
FOR ANY POWER STEALING TYPE
OF THERMOSTAT**



TYPICAL MODELS
HONEYWELL: T8400, T8000, T8700
CHRONOTHERM IV/ MODELS: T8500 & T8600
WHITE ROGERS: 1F90-371

CONNECT RESISTOR BETWEEN
T1/24VAC AND T2

**RESISTOR INSTALLATION
FOR ANY POWER STEALING TYPE
OF THERMOSTAT**



TYPICAL MODELS
HONEYWELL: T8400, T8000, T8700
CHRONOTHERM IV/ MODELS: T8500 & T8600
WHITE ROGERS: 1F90-371

CONNECT RESISTOR BETWEEN
T1/24VAC AND T2