## Wiring Diagrams for CAS Units

## CAS-3, 6, and 7, Power Vent, Single Oil-Fired System with Standard Primary Control

**Customer Service: 252.522.3031** 

