

S2000 & S2020 Humidifier
Low Voltage Terminal Block



Disconnect the wires from the "A" terminals and check the device & circuit with a reliable ohm meter. Check continuity when the fan is off and when it is running.

